
Embedded Systems with ARM Cortex-M3 Microcontrollers in Assembly Language and C

Chapter 8 Passing Parameters to Subroutines via Registers

Dr. Yifeng Zhu Electrical and Computer Engineering University of Maine

Spring 2015

Link Register



Calling a Subroutine

BL label

- Step 1: LR = PC + 4
- Step 2: PC = label

Notes:

- label is name of subroutine
- Compiler translates label to memory address
- After call, LR holds return address (the instruction following the call)

```
MOV r4, #100
...
BL foo
...
```

```
Subroutine/Callee

foo PROC
...
MOV r4, #10
...
BX LR
ENDP
```

Exiting a Subroutine

BX LR

```
\triangleright PC = LR
```

MOV r4, #100 ... BL foo

```
foo PROC
...
MOV r4, #10
...
BX LR
ENDP
```


BL and BX

```
void enable(void);
   enable();
      Compiler
                                export enable
 BL enable
                              enable
                                         BX LR
```


ARM Procedure Call Standard


Register	Usage	Subroutine Preserved	Notes
r0	Argument I and return value	No	If return has 64 bits, then r0:r1 hold it. If argument 1 has 64 bits, r0:r1 hold it.
rl	Argument 2	No	
r2	Argument 3	No	If the return has 128 bits, r0-r3 hold it.
r3	Argument 4	No	If more than 4 arguments, use the stack
r4	General-purpose VI	Yes	Variable register 1 holds a local variable.
r5	General-purpose V2	Yes	Variable register 2 holds a local variable.
r6	General-purpose V3	Yes	Variable register 3 holds a local variable.
r7	General-purpose V4	Yes	Variable register 4 holds a local variable.
r8	General-purpose V5	YES	Variable register 5 holds a local variable.
r9	Platform specific/V6	No	Usage is platform-dependent.
rI0	General-purpose V7	Yes	Variable register 7 holds a local variable.
rll	General-purpose V8	Yes	Variable register 8 holds a local variable.
rI2 (IP)	Intra-procedure-call register	No	It holds intermediate values between a procedure and the sub-procedure it calls.
rI3 (SP)	Stack pointer	Yes	SP has to be the same after a subroutine has completed.
rI4 (LR)	Link register	No	LR does not have to contain the same value after a subroutine has completed.
r15 (PC)	Program counter	N/A	Do not directly change PC


Link Register





```
MOV R0,#3
      MOV R1,#4
                                    R1: second argument
      BL SSQ
      MOV R2, R0
                               R0: first argument
       B ENDL
SSQ MUL R2,R0,R0
                                    int SSQ(int x, int y){
                                      int z;
      MUL R3,R1,R1
                                      z = x*x + y * y;
      ADD R2, R2, R3
                                      return z;
      MOV R0, R2
      BX LR
                                R0: Return Value
```


























MOV R0,#3 MOV R1,#4 BL SSQ MOV R2, R0 **B ENDL** SSQ MUL R2, R0, R0 MUL R3, R1, R1 ADD R2, R2, R3 MOV RO, R2 BX LR **ENDL**







MOV R0,#3 MOV R1,#4 BL SSQ MOV R2, R0 **B ENDL** SSQ MUL R2, R0, R0 MUL R3,R1,R1 ADD R2, R2, R3 MOV RO, R2 BX LR **ENDL**

